

USER INTERFACE		UI ELEMENT	
TOOLS		MANAGER	
210		211	
COMMAND AND		NEARBY DEVICE	
CONTROL TRANSLATION		LIST	
212		214	
AUTHORIZATION MODULE 216	DEVICE DETECTION TOOLS 218		DEVICE CONNECTION MANAGER 220
N	ETWORK S MOD 22		

FIG. 3




FIG. 4A




FIG. 4B




FIG. 4C




FIG. 5A




FIG. 5B




FIG. 6A




FIG. 6B




FIG. 7A




FIG. 7B




FIG. 7C




FIG. 8A




FIG. 8B




FIG. 9